

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration General Description Features

The MAX8895\_ USB-compliant linear battery chargers operate from either a USB port or dedicated charger with automatic detection of adapter type and USB enumeration capability. The MAX8895\_ integrate the battery disconnect switch, current-sense circuit, MOSFET pass elements, and thermal regulation circuitry, and eliminate the external reverse-blocking Schottky diode to create the simplest and smallest stand-alone charging solutions.

The MAX8895\_ includes an automated detection of charge adapter type, making it possible to distinguish between USB 2.0 device, USB charger, and dedicated charger devices. Furthermore, the MAX8895\_ include a USB enumeration function that automatically negotiates with a USB host, making it possible to achieve the highest current available from a USB 2.0 device or USB charger without processor intervention. The adapter type detection is compliant with USB 2.0 specification as well as USB charging Revision 1.1.

The MAX8895\_controls the charging sequence for singlecell Li+ batteries from initial power-OK indication, through prequalification, fast-charge, top-off, and finally charge termination. Charging is controlled using constant current, constant voltage, and constant die-temperature (CCCVCTj) regulation for safe operation under all conditions. The maximum charging current is adaptively controlled by subtracting the system current from the input current limit, ensuring that the charging current is always maximized for any given operating condition.

The MAX8895\_ features optimized smart power control to make the best use of limited USB or adapter power. Battery charge current is set independently of the SYS\_ input current limit. Power not used by the system charges the battery. Automatic input selection switches the system from battery to external power. This allows the application to operate without a battery, discharged battery, or dead battery.

Other features include undervoltage lockout (UVLO), overvoltage protection (OVP), charge status flag, charge fault flag, power-OK monitor, battery thermistor monitor, charge timer, and a 3.3V output.

The MAX8895\_ operates from a +4.0V to +6.6V supply and include overvoltage protection up to +16V. The MAX8895\_ is specified over the extended temperature range (-40°C to +85°C) and are available in a compact 2.36mm x 2.36mm, 25-bump WLP package (0.4mm pitch).

- Enables Charging from a USB Port\*
- Automatic Detection of Adapter Type
- Enumeration Capability Without Processor Intervention
- USB Low-Speed Operation Without External Crystal (MAX8895V/MAX8895W/MAX8895X)
- USB Full-Speed Operation Using an External Crystal (MAX8895Y)
- Compliant with USB 2.0 Specification
- Compliant with USB Charging Specification (Revision 1.1)
- Adaptive Input Current Limit for Dedicated Charger
- Input Overvoltage Protection to 16V
- Automatic Current Sharing Between Battery Charging and System
- ♦ Smart Power Selector<sup>™</sup> Allows Operation with Discharged or No Battery
- NTC Monitoring of Battery Temperature
- No External MOSFETs Required
- Thermal Regulation Prevents Overheating
- ♦ 2µA Shutdown Current
- Tiny 2.36mm x 2.36mm, 25-Bump, 0.4mm Pitch WLP Package

### Applications

Bluetooth<sup>®</sup> Headsets Charging Cradles Portable Devices

<u>Ordering Information and Typical Operating Circuit</u> appear at end of data sheet.

Bluetooth is a registered trademark of Bluetooth SIG.

Smart Power Selector is a trademark of Maxim Integrated Products, Inc. \*Protected by US Patent #6,507,172.

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **ABSOLUTE MAXIMUM RATINGS**

BUS_ to AGND	0.3V to +16.0V
XIN, XOUT, INT_3V3 to AGND	-0.3V to +4.0V
ENU_EN, SUS_EN, RWU, D+, D-, PF	REQ, CHG, UOK,
FLT, BAT_, SYS_, CEN, STDBY, DI	ET_DONE,
IBUS_DEF, CHG_TYPE to AGND	-0.3V to +6.0V
KB_TM, ISET, THM, IDN,	
CT to AGND	-0.3V to (VINT_3V3 + 0.3V)
DGND to AGND	0.3V to + 0.3V

25-Bump, 2.36mm x 2.36mm WLP	
(derate 19.34mW/°C above +70°C)	1560mW
Operating Temperature	40°C to +85°C
Junction Temperature	+150°C
Storage Temperature Range	65°C to +150°C
Soldering Temperature (reflow)	+260°C

Stresses beyond those listed under "Absolute Maximum Ratings" may cause permanent damage to the device. These are stress ratings only, and functional operation of the device at these or any other conditions beyond those indicated in the operational sections of the specifications is not implied. Exposure to absolute maximum rating conditions for extended periods may affect device reliability.

#### **ELECTRICAL CHARACTERISTICS**

 $(THM = \overline{CEN} = SUS_EN = AGND, VBAT_ = 4.2V, VBUS_, CT, \overline{PREQ}, \overline{CHG}, \overline{UOK}, \overline{FLT}, \overline{DET_DONE}$  are unconnected,  $T_A = -40^{\circ}C$  to +85°C, unless otherwise noted. Typical values are at  $T_A = +25^{\circ}C$ .) (Note 1)

PARAMETER	SYMBOL	CONDITIONS			MIN	TYP	MAX	UNITS
USB-TO-SYS PREREGULAT	DR							
USB Operating Range		Initial VBUS voltage before enabling charger			4.0		6.6	V
USB Standoff Voltage		$V_{BAT} = V_{SYS} = 0V$	, I <sub>BUS_</sub> < 650	)µA (max)			14	V
BUS_OK Debounce Timer	tusb_db	Time from BUS_ with logic-low	iin valid rang	e until <del>UOK</del>		500	650	ms
		UOK logic-low, V <sub>BUS</sub> _rising, 100mV hysteresis	Before initia external dev	l detection of vice	3.85	4.0	4.15	
USB Undervoltage Lockout Threshold		UOK logic-low, VBUS_ falling	USB 2.0 low device	v-power	3.75	3.9	4.05	V
Threshold		UOK logic-low, V <sub>BUS</sub> _falling	USB 2.0 hig device	h-power	3.95	4.1	4.25	v
		UOK logic-low, V <sub>BUS</sub> _falling	Dedicated o USB charge		Vsys_ -100mV	V <sub>SYS</sub> _ + 50mV	V <sub>SYS</sub> _ + 200mV	
USB Overvoltage Protection Threshold		UOK logic-low, VBUS	6_ rising, 100	ImV	6.8	6.95	7.1	V
	IDETECT	Charge type detection, ISYS_ = IBAT_ = 0mA, MAX8895W/ MAX8895X				0.5		
		$V\overline{CEN} = 0V$		MAX8895Y			2.5	
	IENUMERATE	USB 2.0 enumeration in progress, ISYS_ = IBAT_ = 0mA, VCEN = 0V					100	
USB Input Supply Current (Note 2)	ISUSPEND	Suspend mode, ISYS 0mA, VSTDBY = 3.3V	Suspend mode, ISYS_ = IBAT_ =				0.5	mA
				MAX8895Y			2.5	
		USB 2.0 low-power	$T_A = 0^{\circ}C$ 1	:o +85°C			100	
	IUSB_100mA	device detected	$T_{A} = -40^{\circ}$	C to +85°C			102.5	
	IUSB_500mA	USB 2.0 high-power device detected					500	
	Isus	During suspend				0		
USB Input Current Limit	IENU	During USB enumera	ation		40	45	55	mA
	IUSB_LP	USB 2.0 low-power of	device detec	ted	80	90	98	
	IUSB_HP	USB 2.0 high-power	device dete	cted	460	475	490	

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### ELECTRICAL CHARACTERISTICS (continued)

 $(THM = \overline{CEN} = SUS_EN = AGND, V_{BAT_} = 4.2V, V_{BUS_}, CT, \overline{PREQ}, \overline{CHG}, \overline{UOK}, \overline{FLT}, \overline{DET_DONE}$  are unconnected,  $T_A = -40^{\circ}C$  to +85°C, unless otherwise noted. Typical values are at  $T_A = +25^{\circ}C$ .) (Note 1)

PARAMETER	SYMBOL	CON	DITIONS	MIN	TYP	MAX	UNITS	
V <sub>BUS_</sub> -to-V <sub>SYS</sub> _On- Resistance		V <sub>BUS</sub> = V <u>CEN</u> = 5V, I	SYS_ = 400mA		200	320	mΩ	
V <sub>SYS</sub> to-V <sub>BAT</sub> _ Reverse Regulation		When SYS is in regula stops, VSYS_ falling, 5		VBAT_ - 80mV	V <sub>BAT</sub> _ - 50mV	V <sub>BAT_</sub> - 20mV	V	
Input Limiter Soft-Start Time		Input current ramp tin	ne		50	100	μs	
Thermal-Limit Start Temperature	TDIE_LIM				+110		°C	
Thermal-Limit Start Temperature Hysteresis					10		°C	
Thermal-Limit Gain		ISYS_ reduction/die tem	perature (above +110°C)		5		%/°C	
V <sub>BUS</sub> _Adaptive Current Regulation Threshold		V <sub>BUS</sub> regulation three current limit is regulat charger or USB charg	ed for dedicated			V <sub>SYS</sub> _+ 550mV	V	
SYS_ Regulation Voltage		$V_{BAT} > 3.45V, I_{SYS}$ $V_{BUS} = V\overline{CEN} = 5V$	= 1mA to 1.6A,			V <sub>BAT_</sub> + 210mV	V	
Minimum SYS Regulation Voltage		$V_{BUS} = 6V, I_{SYS} = 1$ $V_{\overline{CEN}} = 5V$	ImA to 1.6A,	3.3	3.4	3.55	V	
CHARGER								
BATto-SYS_ On-Resistance		$I_{SYS} = 200 mA$			55	80	mΩ	
BAT_ Undervoltage Lockout	VBAT_UVLO_F	VBAT_ falling		2.60	2.85	3.1	V	
	VBAT_UVLO_R	V <sub>BAT</sub> _ rising		2.75	3.00	3.25	v	
Charger Soft-Start Time		Charge-current ramp	time		1		ms	
BAT_ Leakage Current		VBUS_ not connected			2	6	μA	
		VBUS_ connected, VC	$\overline{EN} = 5V$		2	6	P	
PRECHARGE MODE	1	r		<u>,</u>				
BAT_ Precharge-Current Set Range	IPCHG	RISET = $30k\Omega$ to $1.875$ (Note 3)	5kΩ, VBAT_ >1.4V		IFCHG/10		А	
BAT_ Prequalification	VBAT_PCHG_R	VBAT_ rising		2.7	2.8	2.9	V	
Threshold	VBAT_PCHG_F	V <sub>BAT</sub> _falling		2.6	2.7	2.8	v	
FAST-CHARGE MODE		1		,				
BAT_ Charge-Current Set Range	IFCHG	RISET = $30k\Omega$ to $1.875$ (Note 3)	5kΩ, VBAT_>1.4V	0.1		1.85	А	
nange		ISET = INT_3V3 (Note	e 3)		600		mA	
BAT_ Charge-Current			$RISET = 1.875k\Omega$		1850			
Accuracy, Charger Loop in		V <sub>BUS</sub> = 5.5V (Note 3)	$R_{ISET} = 5k\Omega$	540	600	660	mA	
Control			$RISET = 30k\Omega$	90	100	110		
PAT Foot Charge Threshold	VBAT_FCHG_R	VBAT_ rising threshold current IFCHG is redu		3.9	4.0	4.1	V	
BAT_ Fast-Charge Threshold	VBAT_FCHG_F	VBAT_ falling threshold, where charging current is increased to IFCHG		3.7	3.8	3.9	V	

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **ELECTRICAL CHARACTERISTICS (continued)**

 $(THM = \overline{CEN} = SUS_EN = AGND, V_{BAT_} = 4.2V, V_{BUS_}, CT, \overline{PREQ}, \overline{CHG}, \overline{UOK}, \overline{FLT}, \overline{DET_DONE}$  are unconnected,  $T_A = -40^{\circ}C$  to +85°C, unless otherwise noted. Typical values are at  $T_A = +25^{\circ}C$ .) (Note 1)

PARAMETER	SYMBOL	CONDITIONS		MIN	TYP	MAX	UNITS
TOP-OFF CHARGE MODE		·					
Top-Off Charge Current	ITCHG	$R_{ISET} = 30k\Omega$ to 1.875	$R_{ISET} = 30k\Omega$ to 1.875k $\Omega$ (Note 3)		0.6 x IFCHG		А
BAT_ Charge Termination		$R_{IDN} = 240 k\Omega$ to $15 k\Omega$	2	10		160	
Current Range	ICHG_DONE	IDN = INT_3V3			80		mA
BAT_ Regulation Voltage	VBAT_REG	I <sub>BAT_</sub> = 0mA	$T_A = +25^{\circ}C$	4.179	4.200	4.221	V
	VBAT_REG		$T_A = 0^{\circ}C \text{ to } +85^{\circ}C$	4.158	4.200	4.242	v
BAT_ Recharge Threshold	VBAT_RECHG	Recharge threshold in restate going into top-off r	elation to V <sub>BAT</sub> in DONE node (Figure 20)	-100	-200	-300	mV
CHARGE TIMER		·					
Maximum Prequalification	tpchg	From VCEN falling to end of prequalification	CT = 0.068µF		16		Min
Time	UPCHG	charge mode, VBAT_ = 2.5V	C <sub>T</sub> = AGND		20		IVIIII
Maximum Fast-Charge Time	t <sub>FCHG</sub>	From VCEN falling to	$C_{T} = 0.068 \mu F$		100		Min
Maximum rast onarge nine	FCHG	VFLT falling	$C_T = AGND$		120		
Maintain-Charge Time	<sup>t</sup> MTCHG	CT = 0.068µF		4			Min
Maintain-Onarge Time			$C_T = AGND$		5		
Timer Accuracy		CT = 0.068µF		-30		+30	%
		CT connected to AGND		-30		+30	/0
Timer Extend Threshold		Percentage of charge timer clock operates a			50		%
Timer Suspend Threshold		Percentage of charge timer clock pauses	current below which		20		%
ADAPTER TYPE DETECTION	l	•					
D- Current Sink		MAX8895V/MAX8895>	(/MAX8895Y	50	86	150	
D- Current Sink	IDM_SINK	MAX8895W		64	86	102	μA
D+ Source Voltage	VDP_SRC	IDP_SRC = 0 to 200µA		0.5	0.6	0.7	V
D+ Detection Threshold	VDAT_REF			0.25	0.32	0.40	V
D+ Source On-Time	tDP_SRC_ON			100			ms
D+ Source to High Current Time	tDP_SRC_HC			40			ms
D- Pullup Resistor	R <sub>DM_PU</sub>	MAX8895V/MAX8895W/MAX8895X only, external series resistor = $33\Omega$		1.425	1.500	1.575	kΩ
D+ Pullup Resistor	R <sub>DP_PU</sub>	MAX8895Y only, external series resistor = $33\Omega$		1.425	1.500	1.575	kΩ
D+ Charger Detection Pullup Resistor	RDP_CD_PU	RDP_CD_PU connect to INT_3V3		200	330	600	kΩ
D- Weak Current Sink	IDM_CD_PD					0.1	μA
D- Logic-High Threshold	Vdm_ih			0.8		2.0	V

# **Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration**

### ELECTRICAL CHARACTERISTICS (continued)

 $(THM = \overline{CEN} = SUS_EN = AGND, V_{BAT_} = 4.2V, V_{BUS_}, CT, \overline{PREQ}, \overline{CHG}, \overline{UOK}, \overline{FLT}, \overline{DET_DONE}$  are unconnected, TA = -40°C to +85°C, unless otherwise noted. Typical values are at TA = +25°C.) (Note 1)

PARAMETER	SYMBOL	CONI	DITIONS	MIN	TYP	MAX	UNITS	
Enumeration Time Limit	tenum	Time from start of enu until enumeration mus not completed, the MA enumerate	t be completed; if		10		S	
Reconnect Timer	<b>t</b> FAULT	Time from failed enum detection reenabled	neration to adapter type		3		S	
Enumeration Fail to Reconnect Timer	tenu_fault	Time from enumeratio enumeration is retried enumeration fail at 100 timer is started	at 100mA or time from		87		ms	
Reenumeration Timer	<sup>t</sup> RE_ENUM	Time from when the M suspend mode until it RWU = AGND			100		ms	
Oscillator Frequency Accuracy		MAX8895V/MAX8895X oscillator), $T_A = +25^{\circ}C$		5.91	6.00	6.09	MHz	
XIN Input Current		MAX8895Y only, VXIN	= VSTDBY = 3.3V			10	μA	
XIN Logic-High Input Voltage		MAX8895Y only		2/3x VINT_3V3		Vint_3v3	V	
XIN Logic-Low Input Voltage		MAX8895Y only				0.4	V	
тнм								
THM Cold Threshold	TAMB_COLD	When charging is sus threshold, 2% hystere		72	74	76	% of VINT_3V3	
THM Hot Threshold	TAMB_HOT	When charging is sus threshold, 2% hystere		26	28	30	% of VINT_3V3	
THM Threshold, Disabled		When THM function is threshold, 2% hystere	0		3		% of VINT_3V3	
THM Input Leakage		THM = AGND or	$T_A = +25^{\circ}C$	-0.1	0.001	+0.2	μA	
		INT_3V3	$T_A = +85^{\circ}C$		0.01		μΑ	
LOGIC I/O: CHG, FLT, UOK, C	EN, PREQ, K		SUS_EN, ENU_EN, DET	DONE, C	HG_TY	PE, IBUS_	DEF	
		High level		1.3			V	
Logic-Input Threshold		Low level				0.4		
		Hysteresis			50		mV	
Logic-Input Leakage Current		$V_{BUS} = 0$ to 5.5V	$T_A = +25^{\circ}C$		0.001	1	μA	
			$T_A = +85^{\circ}C$		0.01		F., ,	
Logic-Low Output Voltage (CHG, FLT, UOK, PREQ, DET_DONE, CHG_TYPE Only)		Sinking 10mA			35	100	mV	
Logic-High Output-Leakage Current (CHG, FLT, UOK,		$T_A = +25^{\circ}C$ V <sub>SYS</sub> = 5.5V			0.001	1	μA	
PREQ, DET_DONE, CHG_ TYPE Only)			$T_A = +85^{\circ}C$		0.01			

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **ELECTRICAL CHARACTERISTICS (continued)**

 $(THM = \overline{CEN} = SUS_EN = AGND, V_{BAT_} = 4.2V, V_{BUS_}, CT, \overline{PREQ}, \overline{CHG}, \overline{UOK}, \overline{FLT}, \overline{DET_DONE}$  are unconnected,  $T_A = -40^{\circ}C$  to +85°C, unless otherwise noted. Typical values are at  $T_A = +25^{\circ}C$ .) (Note 1)

PARAMETER	SYMBOL	CONDITIONS	MIN	TYP	MAX	UNITS	
USB DATA INTERFACE							
Differential-Receiver Input Sensitivity		IV <sub>D+</sub> - V <sub>D-</sub> I	0.2			V	
Differential-Receiver Common-Mode Voltage			0.8		2.5	V	
D+, D- Input Impedance			300			kΩ	
D+, D- Output Low Voltage	Vol	$R_{LOAD} = 1.5 k\Omega$ from V <sub>D</sub> - to 3.6V			0.3	V	
D+, D- Output High Voltage	Voh	$R_{LOAD} = 15k\Omega$ from D+ and D- to AGND	2.8		3.6	V	
Driver Output Impedance		Excludes external resistor	2	7	11	Ω	
BUS_ Idle Time	tidle	Only valid when an adapter type is detected as a USB 2.0 device; time BUS_ is inactive until charging current is reduced to ISUSPEND		3		ms	
USB Host Remote Wake-Up Timer	tRWU	Time delay from when the MAX8895_ is put into suspend mode until they request the host for a remote wake-up		100		ms	
D+, D- Rise Time (Note 5)	tRISE	$\begin{array}{l} \mbox{MAX8895V/MAX8895W/MAX8895X only, } C_{L} = \\ \mbox{50pF to 600pF, (Figures 5 and 6)} \end{array}$	75		250	ns	
(NOLE 5)		MAX8895Y only, $C_L = 50 pF$ (Figures 5 and 6)	4		20		
D+, D- Fall Time	+	MAX8895V/MAX8895W/MAX8895X only, $C_L = 50$ pF to 600 pF (Figures 5 and 6)	75		250		
(Note 5)	tfall	MAX8895Y only, CL = 50pF (Figures 5 and 6)	4		20	ns	
Rise-/Fall-Time Matching		eq:maxsessessessessessessessessessessessesses	80		120	%	
(Note 5)		MAX8895Y only, C <sub>L</sub> = 50pF (Figures 5 and 6)	90		110	70	
Output-Signal Crossover		MAX8895V/MAX8895W/MAX8895X only, $C_L = 50$ pF to 600 pF (Figures 5 and 6)	1.3		2.0	V	
Voltage (Note 5)		MAX8895Y only, C <sub>L</sub> = 50pF (Figures 5 and 6)	1.3		2.0	V	
INT_3V3 REGULATOR							
INT_3V3 Voltage		V <sub>BUS</sub> = 5V, I <sub>INT</sub> 3v3 = 0 to 10mA	3.0	3.3	3.6	V	
ESD PROTECTION (D+, D-, V	'BUS_)						
Human Body Model		VBUS_ bypassed with 1µF to AGND		±8		kV	

Note 1: Specifications are 100% production tested at T<sub>A</sub> = +25°C. Limits over the operating temperature range are guaranteed by design and characterization.

Note 2: Sum of input current limit and current used for INT\_3V3.

Note 3: Maximum charging current is adaptively regulated to IIN\_LIM - ISYS\_ with a maximum value of ICHG.

**Note 4:** All devices are 100% production tested at  $T_A = +25^{\circ}C$ . Limits over the operating temperature range are guaranteed by design. **Note 5:** Guaranteed by design, not production tested.

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **Typical Operating Characteristics**

 $(V_{BAT} = 4.2V, V_{BUS} = 5V, ISET = IDN = CT = SUS_EN = INT_3V3, STDBY = \overline{ENU_EN} = RWU = \overline{CEN} = KB_TM = AGND, circuits of Figures 4 and 5 (MAX8895V/MAX8895X and MAX8895Y, respectively), TA = +25°C, unless otherwise noted.)$ 



Maxim Integrated

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

**\_\_\_\_Typical Operating Characteristics (continued)** 

 $(V_{BAT} = 4.2V, V_{BUS} = 5V, ISET = IDN = CT = SUS_EN = INT_3V3, STDBY = \overline{ENU_EN} = RWU = \overline{CEN} = KB_TM = AGND, circuits of Figures 4 and 5 (MAX8895V/MAX8895X and MAX8895Y, respectively), T<sub>A</sub> = +25°C, unless otherwise noted.)$ 



Maxim Integrated

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **Typical Operating Characteristics (continued)**

 $(V_{BAT} = 4.2V, V_{BUS} = 5V, ISET = IDN = CT = SUS_EN = INT_3V3, STDBY = \overline{ENU_EN} = RWU = \overline{CEN} = KB_TM = AGND, circuits of Figures 4 and 5 (MAX8895V/MAX8895X and MAX8895Y, respectively), TA = +25°C, unless otherwise noted.)$ 







**MAX8895Y EYE DIAGRAM** 







MAX8895V/W/X EYE DIAGRAM



DEDICATED CHARGER CONNECT



### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **Typical Operating Characteristics (continued)**

 $(V_{BAT} = 4.2V, V_{BUS} = 5V, ISET = IDN = CT = SUS_EN = INT_3V3, STDBY = \overline{ENU_EN} = RWU = \overline{CEN} = KB_TM = AGND, circuits of Figures 4 and 5 (MAX8895V/MAX8895X and MAX8895Y, respectively), TA = +25°C, unless otherwise noted.)$ 















Maxim Integrated

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **Typical Operating Characteristics (continued)**

 $(V_{BAT} = 4.2V, V_{BUS} = 5V, ISET = IDN = CT = SUS_EN = INT_3V3, STDBY = \overline{ENU_EN} = RWU = \overline{CEN} = KB_TM = AGND, circuits of Figures 4 and 5 (MAX8895V/MAX8895X and MAX8895Y, respectively), T<sub>A</sub> = +25°C, unless otherwise noted.)$ 



### **Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration**

### **Pin Configurations**



# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **Pin Description**

	NAME			
PIN	MAX8895W	MAX8895V/ MAX8895X	MAX8895Y	FUNCTION
A1	ISET	ISET	ISET	Maximum Fast-Charge Current Selection. Connect a resistor from ISET to AGND to set the fast-charge current from 0.1A to 1.85A. IFCHG = 3000/RISET If ISET is connected to INT_3V3 the default IFCHG is set as maximum charge current. ISET can also be used to monitor the actual current charging the battery. See the <i>Monitoring Charge Current</i> section for details.
A2	STDBY	STDBY	STDBY	Standby Mode Enable. Connect STDBY to AGND to enter automatic detect mode. In automatic detect mode, the MAX8895V/MAX8895W/MAX8895X determine when to enter suspend mode depending on the status of the SUS_EN logic input. When using the MAX8895Y, the IC always starts in automatic suspend mode. Connect STDBY to INT_3V3 or drive logic-high to force the MAX8895_ into suspend mode regardless of external conditions.
A3	BAT_A	BAT_A	BAT_A	Li+ Battery Connection (V <sub>BAT_</sub> ). Connect a single-cell Li+ battery from V <sub>BAT_</sub> to DGND. The battery charges from V <sub>SYS_</sub> when a valid source is present at V <sub>BUS_</sub> . V <sub>BAT_</sub> powers V <sub>SYS_</sub> when V <sub>BUS_</sub> power is not present, or when
B3	BAT_B	BAT_B	BAT_B	the V <sub>SYS</sub> load exceeds the input current limit. Bypass V <sub>BAT</sub> to DGND with a 10 $\mu$ F X5R or X7R ceramic capacitor. Both BAT_A and BAT_B must be connected together externally.
A4	SYS_A	SYS_A	SYS_A	System Supply Output (V <sub>SYS</sub> ). V <sub>SYS</sub> is connected to V <sub>BAT</sub> through an internal 55m $\Omega$ system load switch when V <sub>BUS</sub> is invalid, or when the V <sub>SYS</sub> load is greater than the input current limit. When a valid voltage is present at V <sub>BUS</sub> , V <sub>SYS</sub> is limited to 4.35V when using the MAX8895V/MAX8895X/MAX8895Y, and 4.53V when using the MAX8895W. When the system load
B4	SYS_B	SYS_B	SYS_B	current (ISYS_) exceeds the VBUS_ current limit VBAT_ also powers VSYS_ to maintain the load current. Bypass VSYS_ to DGND with a 10µF X5R or X7R ceramic capacitor. Both SYS_A and SYS_B must be connected together externally.
A5	BUS_A	BUS_A	BUS_A	USB Power Input (V <sub>BUS</sub> ). During initial connection of an external device, the MAX8895_ identifies the type of connection established and set the input current limit accordingly. Bypass V <sub>BUS</sub> to DGND with a $10\mu$ F X5R or X7R
B5	BUS_B	BUS_B	BUS_B	ceramic capacitor. Both BUS_A and BUS_B must be connected together externally.
B1	IDN	IDN	IDN	Charge Termination Current Threshold. Connect a resistor from IDN to AGND to set the termination current threshold from 10mA to 160mA. ITERM = 2400/RIDN If IDN is connected to INT_3V3, the termination current is set to the default ICHG_DONE threshold.

# **Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration**

### Pin Description (continued)

	NAME			
PIN	MAX8895W	MAX8895V/ MAX8895X	MAX8895Y	FUNCTION
B2		CHG	CHG	Active-Low, Charging Indicator. CHG is an open-drain output that is pulled low when the battery is in prequalification mode, fast-charge mode, or top-off states. Otherwise, CHG is high impedance.
DZ	CHG_TYPE		_	CHG_TYPE is used to indicate capacity of input current. IF CHG_TYPE is high, the input current can be greater than or equal to 500mA. If CHG_TYPE is low, the input current is 100mA from the USB 2.0 host.
		_	XIN	Crystal Oscillator Input. Connect XIN to one side of a parallel resonant 12MHz ±0.25% crystal and a capacitor to AGND. XIN can also be driven by an external clock referenced to INT_3V3.
C1	_	ENU_EN	_	Automatic Enumeration Enable. Connect ENU_EN to AGND to allow the MAX8895V/MAX8895X to automatically perform enumeration. Connect to INT_3V3 or drive logic-high to force the input current limit to 100mA without performing an adapter type detection.
	ENU_EN	_		Automatic Enumeration Enable. Connect ENU_EN to AGND to allow the MAX8895W to automatically perform enumeration. By connecting ENU_EN to INT_3V3 or drive logic-high, disables automatic enumeration and sets the input current limit to level determined by the IBUS_DEF if a USB 2.0 device is detected.
	_	PREQ	PREQ	Active-Low, Prequalification Charging Output. PREQ is an open-drain output that is pulled low when the charger enters the prequalification state.
C2	DET_DONE		_	Active-Low Adapter-Type Detection Done Output. DET_DONE is an open- drain output that is pulled low when adapter detection is completed. DET_ DONE is high impedance in suspend mode.
C3	UOK	UOK	UOK	Active-Low, VBUS_ Power-OK Output. $\overline{\text{UOK}}$ is an open-drain output that is pulled low when a valid input is detected at VBUS
C4	KB_TM	KB_TM	KB_TM	Keyboard Test Mode. In normal operation, connect KB_TM to AGND. This input is only used during USB certification.
C5	AGND	AGND	AGND	Analog Ground. Both AGND and DGND should be connected together at the negative terminal of the battery.
			XOUT	Crystal Oscillator Output. Connect XOUT to one side of a parallel resonant $12$ MHz $\pm 0.25\%$ crystal and a capacitor to AGND. Leave XOUT unconnected if XIN is driven by an external clock.
D1	SUS_EN	SUS_EN	_	Automatic Suspend Mode Detection Enable. Connect SUS_EN to AGND to disable the automatic suspend mode detection. Connect SUS_EN to INT_3V3 or drive logic-high to enable the automatic detection of suspend mode.
		RWU	RWU	Remote Wake-up. Connect RWU to AGND or logic-low for remote wake- ups whenever the device is put into suspend mode and the supervisor determines that more current is needed.
D2	IBUS_DEF	_	_	Sets USB Input Current if Adapter is Detected as a USB 2.0 Device and ENU_EN is Logic-High. If IBUS_DEF is connected high, the input current limit is set to 500mA. If IBUS_DEF is connected low or to ground, the input current limit is set to 100mA.

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

	NAME			
PIN	MAX8895W	MAX8895V/ MAX8895X	MAX8895Y	FUNCTION
D3	CEN	CEN	CEN	Charger Enable Input. Connect $\overline{CEN}$ to AGND to enable battery charging when a valid source is connected at V <sub>BUS</sub> . Connect $\overline{CEN}$ to INT_3V3 or drive logic-high to disable battery charging. In this condition the USB state machine is still active, and V <sub>SYS</sub> is powered from V <sub>BUS</sub> under normal conditions and supplemented from V <sub>BAT</sub> if sufficient current is not available from V <sub>BUS</sub> input.
D4	FLT	FLT	FLT	Active-Low Fault Output. $\overline{\text{FLT}}$ is an open-drain output that is pulled low when the battery charger timer expires before prequalification or fast-charge completes. $\overline{\text{FLT}}$ is also pulled low during adapter type detection or if USB enumeration fails.
D5	D+	D+	D+	USB D+ signal. Connect D+ to a USB "B" connector through a 33 $\Omega$ series resistor. The 1.5k $\Omega$ D+ pullup resistor is internal to the device (for MAX8895Y only).
E1	СТ	СТ	СТ	Timer Set Capacitor. Connect a capacitor from CT to AGND to set the fault timers for prequalification and fast-charge. $t_{PREQUAL} = 16min \times (C_{CT}/0.068\mu F)$ $t_{FCHG} = 100min \times (C_{CT}/0.068\mu F)$ $t_{MTCHG} = 4min \times (C_{CT}/0.068\mu F)$ If CT is connected directly to AGND, the default timers are used.
E2	THM	THM	THM	Thermistor Input. Connect a negative temperature coefficient (NTC) thermistor that has good thermal contact with the battery from THM to AGND. Connect a resistor equal to the thermistor at $T_A = +25^{\circ}$ C resistance from THM to INT_3V3. Charging is suspended when the thermistor is outside the hot and cold limits. Connect THM to AGND to disable the thermistor temperature sensor.
E3	INT_3V3	INT_3V3	INT_3V3	LDO Output. INT_3V3 is the output of an LDO that powers the internal circuitry. INT_3V3 is powered from the VBUS_ input. Connect a $0.1\mu$ F capacitor from INT_3V3 to AGND.
E4	DGND	DGND	DGND	Digital Ground. Both AGND and DGND should be connected together at the negative terminal of the battery.
E5	D-	D-	D-	USB D- Signal. Connect D- to a USB "B" connector through a $33\Omega$ series resistor. The 1.5k $\Omega$ D- pullup resistor is internal to the device (for MAX8895V/MAX8895X only).

### Pin Description (continued)



Figure 1. MAX8895V/MAX8895X Block Diagram



Figure 2. Differential Input Configuration



Figure 3. MAX8895W Block Diagram



Figure 4. MAX8895V/MAX8895X Typical Application Circuit

NAME	VALUE	FUNCTION
CBUS	10µF, 16V	Decoupling of input supply.
C <sub>SYS</sub>	10µF, 6.3V	Decoupling of system rail.
Сват	10µF, 6.3V	Decoupling of battery rail.
RT	User dependent	Thermistor for thermal sensing. See the <i>Thermistor Input (THM)</i> section for details.
RTB, RTP, RTS	User dependent	Bias resistors for thermal sensing. See the <i>Thermistor Input (THM)</i> section for details.
CINT_3V3	0.1µF, 6.3V	Decoupling of internal 3.3V rail.
Сст	1000pF to 0.2µF	Capacitor to set charge timer, optional. See the <i>Fault Output</i> ( <i>FLT</i> ) and <i>Charge Timer</i> ( <i>CT</i> ) section for details.
RISET	1.875k $\Omega$ to 30k $\Omega$	Resistor to set maximum charging current, optional.
RIDN	15k $\Omega$ to 240k $\Omega$	Resistor to set termination current for charger, optional.
R <sub>D+</sub> , R <sub>D-</sub>	33Ω	D+/D- serial impedance.



Figure 5. MAX8895Y Typical Application Circuit

NAME	VALUE	FUNCTION
CBUS	10µF, 16V	Decoupling of input supply.
Csys	10µF, 6.3V	Decoupling of system rail.
CBAT	10µF, 6.3V	Decoupling of battery rail.
RT	User dependent	Thermistor for thermal sensing. See the Thermistor Input (THM) section for details.
RTB, RTP, RTS	User dependent	Bias resistors for thermal sensing. See the Thermistor Input (THM) section for details.
CINT_3V3	0.1µF, 6.3V	Decoupling of internal 3.3V rail.
XTAL	12MHz 2500ppm	MAX8895Y only, clock source for full-speed mode, requires a 2500ppm or better accuracy.
C <sub>XTAL_IN</sub>	User dependent	MAX8895Y only, crystal load capacitor, only required for full-speed operation. See the <i>External Crystal/Ceramic Resonator</i> section for details.
CXTAL_OUT	User dependent	MAX8895Y only, crystal load capacitor, only required for full-speed operation.
Сст	1000pF to 0.2µF	Capacitor to set charge timer, optional. See the <i>Fault Output (FLT) and Charge Timer (CT)</i> section for details.
RISET	1.875k $\Omega$ to 30k $\Omega$	Resistor to set maximum charging current, optional.
RIDN	15k $\Omega$ to 240k $\Omega$	Resistor to set termination current for charger, optional.
RD+, RD-	33Ω	D+/D- serial impedance.



Figure 6. MAX8895W Typical Application Circuit

NAME	VALUE	FUNCTION
CBUS	10µF, 16V	Decoupling of input supply.
Csys	10µF, 6.3V	Decoupling of system rail.
CBAT	10µF, 6.3V	Decoupling of battery rail.
Rthm	User dependent	Thermistor for thermal sensing. See the <i>Thermistor Input (THM)</i> section for details.
RTB, RTP, RTS	User dependent	Bias resistors for thermal sensing. See the <i>Thermistor Input (THM)</i> section for details.
CINT_3V3	0.1µF, 6.3V	Decoupling of internal 3.3V rail.
Сст	1000pF to 0.2µF	Capacitor to set charge timer, optional. See the <i>Fault Output (FLT) and Charge Timer (CT)</i> section for details.
RISET	1.875k $\Omega$ to 30k $\Omega$	Resistor to set maximum charging current, optional.
RIDN	15k $\Omega$ to 240k $\Omega$	Resistor to set termination current for charger, optional.
RD+, RD-	33Ω	D+/D- serial impedance.

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **Detailed Description**

The MAX8895\_ is an integrated 1-cell Li+ charger with USB enumeration capability. All power switches for charging and switching the load between battery and external power are internal. No external MOSFETS are required.

The MAX8895\_ makes it possible to negotiate more than 100mA of charging current from a USB host or hub without processor intervention. The MAX8895\_ also automatically detects a dedicated charger or USB charger and set the input current limit accordingly. The battery charge current can be set up to 1.85A. Input power not used by the system charges the battery.

#### **USB** Interface

An integrated USB peripheral controller provides autoenumeration for full-speed (MAX8895Y) and low-speed (MAX8895V/MAX8895W/MAX8895X) modes.

The USB controller executes the adapter detection sequence, which consists of detecting the type of adapter that is externally connected and setting the input current limit accordingly.

If attached to a USB charger (host or hub) or a USB 2.0 (host or hub), it enumerates as an HID device and negotiates the maximum charging current level (from VBUS\_).

The MAX8895V/MAX8895W/MAX8895X operate in lowspeed mode, using an internal 6MHz oscillator, and does not require an external crystal to be USB compliant. The MAX8895Y operates in full-speed mode and requires an external 12MHz crystal.

According to the USB 2.0 specification, a low-speed device is not allowed to use a standard USB "B" connector. This is why MAX8895\_ is available in both a low- and full-speed version. This makes it possible to use a custom or captive cable for low-speed mode using the MAX8895V/MAX8895W/MAX8895X and still be USB compliant. Operating in full-speed mode, using the MAX8895Y allows use of a standard USB "B" connector.



Figure 7. USB Rise and Fall Timing



Figure 8. Load for D+/D- AC Measurements

#### D+ and D-

The internal USB full speed (MAX8895Y)/low-speed (MAX8895V/MAX8895W/MAX8895X) transceiver is brought out to the bidirectional data pins D+ and D-. These pins are ESD protected up to  $\pm$ 8kV (HBM). Connect these pins to a USB "B" custom connector through external 33 $\Omega$  series resistors. The MAX8895V/MAX8895X provide an automatic switchable 1.5k $\Omega$  pullup resistor for D-, while the MAX8895Y provides an automatic switchable 1.5k $\Omega$  pullup resistor for D+.

#### Adapter Detection

When an adapter is present on  $V_{\text{BUS}}$ , the MAX8895\_ examines the external device to identify the type of adapter connected.

The possible adapter types are:

- Dedicated charger
- USB charger (host or hub)
- USB 2.0 (host or hub) low power
- USB 2.0 (host or hub) high power

Each of these different devices has different current capability as shown in Table 1.

Table 1.	Adapter	Types
----------	---------	-------

ADAPTER TYPE	OUTPUT VOLTAGE	OUTPUT CURRENT
Dedicated charger	4.75V to 5.25V at I <sub>LOAD</sub> < 500mA 2.0V to 5.25V for I <sub>LOAD</sub> ≥500mA	500mA to 1.85A
USB charger	4.75V to 5.25V at I <sub>LOAD</sub> < 500mA 0 to 5.25V for I <sub>LOAD</sub> ≥ 500mA	500mA to 900mA for low speed, full speed 500mA to 1.5A for low speed and full speed
USB 2.0 low power	4.25V to 5.25V	100mA (max)
USB 2.0 high power	4.75V to 5.25V	500mA (max)

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

When an adapter is connected to the MAX8895\_, a series of tests is performed to identify the type of device connected. The sequence is done according to the flow



Figure 9. MAX8895X Flow Chart for Adapter Type Detection

charts in Figures 7 and 8. Figures 9, 10, and 11 show the adapter-type detection timing.



Figure 10. MAX8895V Flow Chart for Adapter Type Detection



Figure 11. MAX8895Y Flow Chart for Adapter Type Detection



Figure 12. MAX8895W Flow Chart for Adapter Type Detection

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration



Figure 13. Flow Chart for Enumeration Process

Once the type of adapter is determined, the MAX8895\_ determines the maximum input current limit, if the external adapter is recognized as a USB charger or USB 2.0 device. The MAX8895\_ then initiates enumeration and determine the maximum input current limit according to Figure 13.

#### Low-Power Mode

Driving STDBY high disables the charger as well as V<sub>SYS</sub>, to reduce the input current drawn from V<sub>BUS</sub>. The current drawn in this mode is less than 500µA for the MAX8895V/MAX8895W/MAX8895X and 2.5mA for the

MAX8895Y. In this mode, the D+ and D- lines become high impedance. When STDBY is high, VSYS\_ is regulated to 50mV (typ) below VBAT\_.

#### USB Suspend

According to the USB rev 2.0 specification, when a USB host stops sending traffic for at least 10ms to a peripheral (MAX8895\_), the peripheral must enter a power-down state called SUSPEND. Once suspended, the peripheral must have enough of its internal logic active to recognize when the host resumes signaling, or if enabled, for generating remote wake-up.

The MAX8895\_ enters SUSPEND state in two ways:

- MAX8895V/MAX8895W/MAX8895X: When no activity is present on D+/D- for 10ms (max), the MAX8895V/ MAX8895W/MAX8895X automatically enters suspend mode to be compliant with USB specification. The MAX8895V/MAX8895W/MAX8895X only enters suspend mode if SUS\_EN is pulled high. When entering suspend mode the MAX8895V/MAX8895W/ MAX8895X disables the charger as well as VSYS to reduce the input current drawn from VBUS . The current drawn in this mode is less than 500µA for the MAX8895V/MAX8895W/MAX8895X, ensuring that the device is compliant with USB specification. In suspend state the bus is IDLE: D+ is low and D- is kept high by the MAX8895V/MAX8895W/MAX8895X pullup resistor. When in suspend mode, VSYS is powered from VBAT . When entering automatic suspend mode, the FLT output is pulled low as an indication that the charger is disabled.
- **MAX8895Y:** When no activity is present on D+/D- for 10ms (max), the MAX8895Y automatically enters suspend mode to be compliant with USB specification. When entering suspend mode, the MAX8895Y disables the charger as well as V<sub>SYS</sub> to reduce the input current drawn from V<sub>BUS</sub>. The current drawn in this mode is less than 2.5mA, ensuring that the device is compliant with the USB specification.

In suspend state, the bus is IDLE: D- is low and D+ is kept high by the MAX8895Y pullup resistor. When in suspend mode, V<sub>SYS</sub> is powered from V<sub>BAT</sub>. When entering automatic suspend mode, the FLT output is pulled low as an indication that the charger is disabled.



Figure 14a. Charger Detection Timing Diagram (MAX8895V/MAX8895X)



Figure 14b. USB Detection Timing Diagram (MAX8895V/MAX8895X)



Figure 15a. Charger Detection Timing Diagram (MAX8895Y)



Figure 15b. USB Detection Timing Diagram (MAX8895Y)



Figure 16a. Charger Detection Timing Diagram (MAX8895W)



Figure 16b. USB Detection Timing Diagram (MAX8895W)

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

#### Wake-Up and USB Resume

The MAX8895\_ can wake up four ways while in suspend mode:

- Logic-high to logic-low transition of STDBY initiating enumeration.
- MAX8895V/MAX8895W/MAX8895X: If STDBY is logic-low and SUS\_EN is logic-high, the MAX8895V/ MAX8895W/MAX8895X monitor the bus activity on the D- line. If the host resumes bus activity, the MAX8895V/MAX8895W/MAX8895X detects this as a 1 to 0 transition on D-. Once this occurs, the device restarts the oscillator and waits for it to stabilize.
- MAX8895Y: If STDBY is logic-low, the MAX8895Y monitors the bus activity on the D+ line. If the host resumes bus activity, the MAX8895Y detects this as a 1 to 0 transition on D+. Once this occurs, the device restarts the oscillator and waits for it to stabilize.
- Remote wake-up is supported by the MAX8895V/ MAX8895X/MAX8895Y, but the remote wake-up feature must be enabled by the host during the enumeration process. Once suspended, the MAX8895V/ MAX8895X/MAX8895Y look at the state of the battery charger. If the charger is not in the done state, the MAX8895V/MAX8895X/MAX8895Y initiate a remote wake-up signal. If the charger is in the done state, a remote wake-up is not initiated before the charger is restarted due to a drop in battery voltage.
- When the MAX8895V/MAX8895X/MAX8895Y initiate a remote wake-up, they first restart the oscillator and wait for the oscillator to stabilize, and then send the remote wake-up event to signal to the host that it needs to be driven out of the suspend status.
- If RWU is connected to ground and the remote wake-up feature has not been set by the host during enumeration, the IC waits tRE\_ENUM after entering suspend mode, then disconnects the pullup resistor and reinitiates the charger type detection.

#### Enumeration

USB bus enumeration is an activity that identifies and assigns unique addresses to devices attached to the bus. Once the MAX8895\_ detects V<sub>BUS\_</sub> is valid for T<sub>USB\_DB</sub>, the MAX8895\_ initiates the detection process to determine the type of device that it is connected to. If the device type is a USB 2.0 host/hub or USB charger, a 1.5k $\Omega$  pullup resistor is connected between D-(MAX8895V/MAX8895W/MAX8895X) or D+ (MAX8895Y) to INT\_3V3.

Enumeration is started on the MAX8895V/MAX8895W/ MAX8895X only if ENU\_EN is logic-low. If ENU\_EN is logic-high, the MAX8895V/MAX8895W/MAX8895X does not connect a pullup resistor between D- and INT\_3V3, and the current limit is set to 100mA regardless of the input type.

When the USB 2.0 host/hub or USB charger detects a plugged-in peripheral (MAX8895\_), it interrogates the peripheral to learn about its capabilities and requirements; and if all is well, configures it to bring it on line. This process is known as enumeration.

During enumeration the host sends multiple requests to the device (MAX8895\_) asking for descriptors (see Table 2) that define the device operation.

All the enumeration tasks are self-managed by the MAX8895\_ serial interface engine (SIE) without any processor intervention.

The SIE supports the following features:

- USB 2.0 low-speed (1.5Mbps): the MAX8895V/ MAX8895W/MAX8895X pulls D- high to indicate to the host that it is a low-speed device
- Full-speed (12Mbps) operation: the MAX8895Y pulls D+ high to indicate to the host that it is a full-speed device
- Human interface device (HID) in the consumer page (MAX8895\_ does not require any custom drivers)
- 8 bytes end-point zero (control end point)
- 1 byte end-point one (INT-IN end point)
- USB suspend/resume support
- Remote wake-up capability

At the end of enumeration (if successful), the device is ready to transfer data (if needed) and enabled to sink the negotiated current from VBUS\_.

Figure 17 shows USB bus traffic as captured by a CATC USB bus analyzer. The traces show a PC (host) enumerating the peripheral (MAX8895V/MAX8895W/ MAX8895X). Notice that the LS field indicates the low-speed (1.5Mbps) operation of the MAX8895V/ MAX8895W/MAX8895X.

 The host uses the default CONTROL end-point EP0 (shown in the "ENDP" boxes) to send a request to the device. The host initially sends requests to address 0 (shown in the ADDR boxes) to communicate with a device to which it has not yet assigned a unique address.

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

								MP	4579			TIME STAMP	00002.3777 4539			TIME STAMP	00002.3881 4499					MP	4459																				
								TIME STAMP	00002.3569 4579		63	TIME	5.000ms 0	TIME STAMP	00002.3817 4515	TIME	s	TIME STAMP	00002.3921 4491			TIME STAMP	00002.4057 4459		51					TIME STAMP	00002.4337 4395												
	22						2	TIME	5.000ms	TIME STAMP	00002.3609 4563			TIME	00002.3			TIME	00002.3		6	TIME	5.000ms	TIME STAMP	00002.4097 4451					TIME	00002.4												
TIME STAMP	00002.2673 4787			0	375	TIME STAMP	00002.3521 4587	S	SCRIPTOR	TIME	21.000ms	DESCRIPTORS	LANG SUPPORTED	TIME	8.000ms	DESCRIPTORS	LANG SUPPORTED	TIME	11.013 ms	TIME STAMP	00002.4009 5299	S	SCRIPTOR	TIME	8.000ms	TIME STAMP	00002.4161 4435	TIME STAMP	00002.4313 4403	TIME	15.000ms												
TIME	6.80ms			TIME STAMP	00002.3145 4675	TIME	6.000ms	DESCRIPTORS	CONFIGURATION DESCRIPTOR	DESCRIPTORS	4 DESCRIPTORS	wINDEX	LANGUAGE ID 0x0000	DESCRIPTORS	USB CHARGER	WINDEX	LANGUAGE ID 0x0000	DESCRIPTORS	USB CHARGER	TIME	5.986ms	DESCRIPTORS	CONFIGURATION DESCRIPTOR	DESCRIPTORS	4 DESCRIPTORS	TIME	18.999ms	TIME	3.000ms	DESCRIPTORS	REPORT DESCRIPTOR												
DESCRIPTORS	DEVICE DESCRIPTOR			TIME	46.999ms	DESCRIPTORS	DEVICE DESCRIPTOR	WINDEX	0x0000	WINDEX				wINDEX	LANGUAGE ID 0x0409		JESTED	wINDEX	LANGUAGE ID 0x0409	DESCRIPTORS	DEVICE DESCRIPTOR	WINDEX	0x0000	WINDEX	0x0000 4	X wLENGTH	0 0	STALL	0x08	wINDEX	0x0000 RE											П	
windex DE	0x0000 DEVICI			X wLENGTH	0 0	WINDEX DES	0x0000 DEVICE	Ч	TYPE, INDEX 0	Τ	TYPE, INDEX 0	wvalue	<b>IGID</b> CODES, REQ			WALUE	NGID CODES REQL		$\square$	WINDEX DES	0x0000 DEVICE	Е	TYPE, INDEX 0	Щ	TYPE, INDEX 0	WINDEX	10N 1 0x0000	WLENGTH	0		PTOR TYPE	TIME STAMP	00002.4457 4371	TIME STAMP	00002.4421 4899	TIME STAMP	00002.4585 4339	TIME STAMP	00002.46494323	TIME STAMP	00002.47134307	TIME STAMP	00002.4777 4843
wVALUE wIN	DEVICE TYPE 0x4	TIME STAMP	00002.2722 1739	WVALUE WINDEX	NEW ADDRESS 3 0x0000	WVALUE WIN	DEVICE TYPE 0x0	WVALUE	<b>CONFIGURATION</b> TYPE, INDEX 0	WVALUE	<b>CONFIGURATION</b> TYPE, INDEX 0		STRING TYPE, LANGID CODES, REQUESTED	WVALUE	STRING TYPE, INDEX 1	~	STRING TYPE, LANGID CODES REQUESTED	WALUE	STRING TYPE, INDEX 1	WVALUE WIN	DEVICE TYPE 0x0	WVALUE	<b>CONFIGURATION</b> TYPE, INDEX 0	WVALUE	<b>CONFIGURATION</b> TYPE, INDEX 0	WVALUE	NEW CONFIGURATION 1	T WVALUE WINDEX	0×0000 0×0000	WVALUE	REPORT_DESCRIPTOR TYPE	TIME	8.009ms	TIME	7.991ms	TIME	8.000ms	TIME	8.000ms	TIME	8.009ms	TIME	7 901ms
bREQUEST	GET_DESCRIPTOR	TIME	52.919ms 00002.	bREQUEST	SET_ADDRESS NEV	bREQUEST	GET_DESCRIPTOR	bREQUEST	GET_DESCRIPTOR	bREQUEST	GET_DESCRIPTOR	bREQUEST	GET_DESCRIPTOR	bREQUEST	GET_DESCRIPTOR	brequest	GET_DESCRIPTOR	bREQUEST	GET_DESCRIPTOR	bREQUEST	GET_DESCRIPTOR	brequest	GET_DESCRIPTOR	bREQUEST	GET_DESCRIPT OR	bREQUEST	SET_CONFIGURATION	D TP R DREQUEST	H_>D C I 0x0A	brequest	GET_DESCRIPTOR	BYTES TRANSFERRED	-	BYTES TRANSFERRED	-	BYTES TRANSFERRED	-	BYTES TRANSFERRED	-	BYTES TRANSFERRED	-	BYTES TRANSFERRED	-
ENDP	0			ENDP	0	ENDP	0	ENDP	0	ENDP	0	ENDP	0	ENDP	0	ENDP	0	ENDP	0	ENDP	-	ENDP	0	ENDP	0	ENDP	0	ENDP	0	ENDP	0	ENDP	-	ENDP		ENDP	-	ENDP	-	ENDP	-	ENDP	-
ADDR	0	E	1ms	ADDR	0	ADDR		ADDR	0	ADDR		ADDR	0	ADDR	0	ADDR	0	ADDR	0	ADDR	0	ADDR	0	ADDR	0	ADDR	0	ADDR	0	ADDR	0	ADDR	ŝ	ADDR	e	ADDR	3	ADDR	33	ADDR	en G	ADDR	e
CONTROL	GET	RESET	25.881ms	CONTROL	SET	CONTROL	GET	CONTROL	GET	CONTROL	GET	CONTROL	GET	CONTROL	GET	CONTROL	GET	CONTROL	GET	CONTROL	GET	CONTROL	GET	CONTROL	GET	CONTROL	SET	CONTROL	SET	CONTROL	GET	INTERRUPT	N	INTERRUPT	N	INTERRUPT	N	INTERRUPT	N	INTERRUPT	N	INTERRUPT	N
	s	DIR	^		s		s	-	s	Ξ	s	Ξ	s	-	s	Ξ	s	-	s	-	s	-	s	-	s	-	s	-	s	-	s	-	s	P	s	-	s	-	s	-	s	-	v
TRANSFER	0	PACKET	69	TRANSFER	-	TRANSFER	2	TRANSFER	3	TRANSFER	4	TRANSFER	5	TRANSFER	9	TRANSFER	7	TRANSFER	8	TRANSFER	6	TRANSFER	10	TRANSFER	Ħ	TRANSFER	12	TRANSFER	13	TRANSFER	14	TRANSFER	15	TRANSFER	16	TRANSFER	17	TRANSFER	18	TRANSFER	19	TRANSFER	00

Figure 17. USB Bus Traffic: MAX8895V/MAX8895W/MAX8895X Enumeration



Figure 18. USB Bus Traffic: MAX8895Y Enumeration

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

- 2) The host begins by sending a Get\_Descriptor\_Device request (Transfer 0 in Figure 16). It does this to determine the maxPacketSize of the device's EP0 buffer (for the MAX8895V/MAX8895X, it is 8 bytes). The host then resets the device by issuing a bus reset (packet 69).
- 3) In transfer 1, the host assigns a unique address to the peripheral by using the Set\_Address request. The assigned address depends on how many other USB devices are currently attached to the host. In this case, the address assigned to our peripheral device (MAX8895V/MAX8895X) is 3. Thereafter, the MAX8895V/MAX8895X respond only to requests directed to address 3. This address remains in force until the host does a bus reset or the device is disconnected. Notice that the peripheral address field (ADDR) in the bus trace changes from 0 to 3 after transfer 1.
- 4) In transfers 2 to 11, the host asks for various descriptors. The device FSM needs to determine from the eight setup bytes which descriptor to send, use this information to access one of several character arrays (ROMs) representing the descriptor arrays.
- 5) In transfer 12, the host requests the device to use the specified configuration (1) and the device enters the configured state.

According to the USB 2.0 specification, a bus powered device can be either low power (it may draw no more than 100mA) or high power (it may draw no more than 500mA).

All devices must default to low power. The transition to high power is under software control (running on the host side). It is the responsibility of software to ensure adequate power is available before allowing devices to consume high-power.

The MAX8895\_ initiates enumeration by asking for 500mA of current. If the MAX8895\_ does not enter configured status before the tENUM (10s, typ), it interprets this as an indication that the host is not able to support the requested current. The MAX8895\_ disconnects the pullup resistor on D- (MAX8895V/MAX8895X)/D+ (MAX8895Y), wait for tENU\_FAULT, and then retry to enumerate, but now as a low current device (100mA). If the MAX8895\_ has still not reached the configured status after tENUM, the MAX8895\_ assumes that either the host is nonresponsive or a wrong adapter type is detected. In this case, the MAX8895\_ disconnects the pullup resistor on D- (MAX8895W/MAX8895X)/D+ (MAX8895Y) and wait for tENU\_FAULT + tFAULT before starting the adapter detection process again.

Figure 18 shows the USB traffic captured during the MAX8895Y enumeration. Notice the field FS indicates the full-speed (12Mbps) operation of the MAX8895Y.

FIELD	LENGTH (bits)	OFFSET (bits)	DECODED	HEXVALUE	DESCRIPTION
bLength	8	0	0x12	0x12	Descriptor size is 18 bytes
bDescriptorType	8	8	0x01	0x01	Device descriptor type
bcdUSB	16	16	0x0200	0x0200	Device compliant to the USB specification version 2.0
bDeviceClass	8	32	0x00	0x00	Each interface specifies its own class information
bDeviceSubClass	8	40	0x00	0x00	Each interface specifies its own subclass information
bDeviceProtocol	8	48	0x00	0x00	No protocols the device basis
bMaxPacketSize0	8	56	0x08	0x08	Maximum packet size for end-point zero is 8
idVendor*	16	64	_	_	Vendor ID is 2922: Maxim Integrated Products
idProduct*	16	80	0x5346	0x5346	Product ID is 21318
bcdDevice	16	96	0x1234	0x1234	The device release number is 1.00
iManufacturer	8	112	0x00	0x00	The device does not have the string descriptor describing the manufacturer
iProduct	8	120	0x01	0x01	The product stringed descriptor index is 1
iSerialNumber	8	128	0x00	0x00	The device does not have the string descriptor describing the serial number
bNumConfigurations	8	136	0x01	0x01	The device has 1 possible configuration

### Table 2. Device Descriptor

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

#### **Smart Power Selector**

The Smart Power Selector seamlessly distributes power between the external VBUS\_ input, the battery (VBAT\_), and the system load (VSYS\_). See Figure 19. The Smart Power Selector basic functions are:

• With both an external adapter and battery connected:

a. When the system load requirements are less than the input current limit, the battery is charged with residual power from the input.

b. When the system load requirements exceed the input current limit, the battery supplies supplemental current to the load.

- When the battery is connected and there is no external power input, the system is powered from the battery.
- When an external power input is connected and there is no battery, the system is powered from VBUS\_.

If the junction temperature starts to get too hot (+110°C typ), the charging rate is reduced. If this is not sufficient to cool down the MAX8895\_, the input current limit is then reduced.

#### System Load Switch

An internal 55m $\Omega$  (typ) MOSFET connects V<sub>SYS</sub> to V<sub>BAT</sub> (Q2, Figure 19) when no voltage source is available at V<sub>BUS</sub> and V<sub>BAT</sub> is above the battery UVLO threshold. When an external source is detected at V<sub>BUS</sub>, this switch controls the charging of V<sub>BAT</sub> and V<sub>SYS</sub> is powered from the valid input source through the input current limiter.

The VSYS\_ - VBAT\_ switch also prevents VSYS\_ from falling below VBAT\_ when the system load exceeds the input current limit. If that should happen, VSYS\_ is allowed to drop to VBAT\_. At this point, the VSYS\_ - VBAT\_ switch turns on so that the battery supplies additional ISYS\_



Figure 19. Smart Power Selector Block Diagram

34

load current. If the system load continuously exceeds the input current limit, then the battery does not charge, even though external power is connected. This is not expected to occur in most cases, since high loads usually occur only in short peaks. During these peaks, battery energy is used, but at all other times the battery charges.

#### **Input Limiter**

The input limiter distributes power from the external adapter to the system load and battery charger. In addition to the input limiter's primary function of passing power to the system and charger, it performs several additional functions to optimize use of available power.

- Input Voltage Limiting: If the VBUS\_ input voltage is above the overvoltage threshold (VBUS\_OVP), the MAX8895\_ enters overvoltage lockout (OVL). OVL protects the MAX8895\_ and downstream circuitry from high-voltage stress up to 16V at VBUS\_. In OVL, VINT\_3V3 remains on, the input switch that sees overvoltage (Q1, Figure 19) opens, FLT is pulled low, and UOK, CHG, DET\_DONE, and PREQ become high-impedance. In OVL, the charger turns off. The VBAT\_ - VSYS\_ switch (Q2, Figure 19) closes, allowing the battery to power VSYS\_. VBUS\_ is also invalid if it is less than VBAT\_, or less than the USB undervoltage threshold (VBUS\_UVLO\_F). With an invalid input voltage, VSYS\_ connects to BAT\_ through a 55m $\Omega$  (typ) switch (Q2, Figure 19).
- Input Overcurrent Protection: The current at V<sub>BUS</sub> is limited to prevent input overload. This current limit is automatically selected to match the capabilities of the adapter source, whether it is a 100mA or 500mA USB 2.0 source, or 500mA to 1.8A for a dedicated adaptor or USB charger. When the load exceeds the input current limit, V<sub>SYS</sub> drops to 50mV (typ) below V<sub>BAT</sub> and the battery supplies supplemental load current.



Figure 20. VSYS\_ Regulation

Maxim Integrated

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration



Figure 21. Adaptive Input Current-Limit Regulation Loop

Thermal Limiting: The MAX8895V/MAX8895X/ MAX8895Y reduce input current by 5%/°C when its die temperature exceeds TDIE\_LIM (+110°C typ). The system load (VSYS\_) has priority over charger current, so the input current is first reduced by lowering the charge current. If the junction temperature still reaches TDIE\_LIM +20°C in spite of charge current reduction, no input VBUS\_ current is drawn, the battery supplies the entire system load, and VSYS is regulated at 50mV (typ) below VBAT\_.

**Note:** The on-chip thermal limiting circuitry is not related to, and operates independently from, the thermistor input.

• Adaptive Battery Charging: While the system is powered from V<sub>BUS</sub>, the charger draws power from V<sub>SYS</sub> to charge the battery. If the combined load between the charger and system exceeds the input current limit, an adaptive charger control loop reduces charge current to prevent the V<sub>SYS</sub> voltage from collapsing.

#### **Regulation Threshold**

The MAX8895\_ always regulates VSYS\_ to 140mV (typ) above V<sub>BAT</sub>\_ with a minimum voltage of 3.4V regardless of what device is connected. The 3.4V minimum voltage regulation reduces the ripple on VSYS\_ during peak load conditions where the input current limit is tripped.

#### **Input Current Limit**

If the connected adapter is a USB 2.0 device the input current limit is set by default to 100mA.

If ENU\_EN is connected to INT\_3V3 or driven logic-high for the MAX8895V/MAX8895X/MAX8895Y, the charger input current limit remains at 100mA. If ENU\_EN is set to logic-high for the MAX8895W the charger's input current limit is determined by the logic state of IBUS\_DEF.

When ENU\_EN is connected to AGND, automatic enumeration is initiated. The MAX8895\_ proceeds to determine if the external USB device is a low- or high-power device and set the input current limit to 100mA or 500mA, respectively. For a dedicated charger or USB charger, the current limit is determined by loading the adapter. When the adapter's output voltage starts to collapse, it is an indication that the current limit of the device is reached.

The MAX8895\_ set the input current limit to regulate VBUS to VSYS +440mV (typ). This ensures that the power dissipation in the MAX8895\_ is kept to a minimum, and at the same time, ensuring that the adapter's current capability is fully utilized. When a dedicated charger is detected, the input current limited is limited by the adaptive input current limit. In this mode, it is up to the adapter to limit the maximum current, which is 1.85A for a dedicated charger and 1.5A for a USB charger, according to the USB charging specification.

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

If the adapter output (V<sub>BUS</sub>) starts to drop below V<sub>SYS</sub> - 440mV (typ), the input current limit function adaptively decreases the input current limit to ensure that the adapter is not overloaded. When the input current limit is reached, the first action taken by the MAX8895\_ is to reduce battery charge current. If, after the charge current is reduced to 0mA, the load at I<sub>SYS</sub> still exceeds the input current limit, V<sub>SYS</sub> begins to fall. When V<sub>SYS</sub> drops to 50mV below V<sub>BAT</sub>, the V<sub>SYS</sub> - V<sub>BAT</sub> switch turns on, using battery power to support the system load during the load peak. See Figure 21 for more information.

#### **Power Monitor Output (**UOK)

UOK is an open-drain output that pulls low when the VBUS\_ input has valid power.

The  $\overline{\text{UOK}}$  monitor has several different thresholds, depending on what type of adapter detected. The different thresholds are as follows:

Table 3. UOK Monitor Thresholds

For USB 2.0 high power

For dedicated charger to USB charger

- The initial detection threshold allows all types of adapters to be detected on V<sub>BUS</sub>. Once the type of adapter is determined, the UVLO threshold is changed.
- For any USB 2.0 device the UVLO thresholds are set to be compliant with USB specifications.
- For a dedicated charger, the UVLO (falling) threshold is lowered to V<sub>SYS</sub> + 50mV (typ) to allow for supporting collapsing charger types, allowing the MAX8895\_ to operate with lower power dissipation.

Note that since the VBUS\_UVLO threshold is changed after initial detection of the device type, there are conditions where the MAX8895\_ can toggle between VBUS\_valid and not valid. This is an indication that the adapter is not within the specified limits.

OVLO (V)

6.9

See Table 3 for more information.

# THRESHOLDS UVLO Initial VBUS\_ detection 4.0V (typ), rising For USB 2.0 low power 3.9V (typ), falling



4.1V (typ), falling

VSYS + 50mV (typ), falling

Figure 22. Charging States

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

#### Soft-Start

To prevent input transients that can cause instability in the USB power source, the rate of change of input current and charge current is limited. When a valid USB 2.0 input is connected, the input current limit is ramped from 0 to 100mA in 50µs. Once enumeration is ended, the current can be ramped to 500mA or to the new input current limit value in 50µs.

When the charger is enabled, the charge current ramps from zero to the final value in 1.5ms (typ). Charge current also ramps when transitioning to fast-charge from prequalification and when changing the USB charge current from 100mA to 500mA.

**Note:** There is no di/dt limiting if I<sub>ISET</sub> is changed suddenly using a switch at RISET.

#### **Battery Charger**

The battery charger has five different states of operation (see Figures 22 and 23):

- **Precharge:** When the battery voltage is below VBAT\_PCHG\_R. In this state, the battery is charged at maximum IPCHG. If the IPCHG > ILIM, then the precharging current is determined by the ILIM (input current limit). Charging a Li+ battery at high charging current when it is fully discharged can cause the battery to become unstable and potentially dangerous. Charging at high charging rates on a fully discharged battery can also reduce life cycles of the Li+ battery.
- **Fast-charge:** In fast-charge mode, the charging current is set to maximum IFCHG. The actual charging current is determined by ILIM ISYS.
- **Top-off charge:** In top-off mode, the battery voltage has almost reached the set point (VBAT\_FCHG\_R). The charging current is reduced in this mode to prevent overcharging the battery, and also to minimize the power dissipation in the battery.
- **Maintenance charge:** The charger enters this mode when the charging current has dropped below the ICHG\_DONE threshold. The charger continues to charge for tMTCHG time to ensure the battery is fully charged before the charger is disabled.
- Charge done: Charger is disabled and only engages again if the battery voltage drops below the VBAT\_RECHG threshold.



Figure 23. Charger Flow Chart

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

#### Charge Enable (CEN)

When <u>CEN</u> is logic-low, the battery charger is enabled. When <u>CEN</u> is logic-high, the battery charger is disabled. <u>CEN</u> does not affect VSYS\_. In many systems, there is no need for the system controller (typically a microprocessor) to disable the battery charger because the MAX8895\_Smart Power Selector circuitry independently manages charging and USB-battery power handover. In these situations, <u>CEN</u> may be connected to ground.

#### Setting Charge Current (ISET)

ISET adjusts the charge current to match the capacity of the battery. The maximum charging current can be fixed by connecting ISET to INT\_3V3 or can be adjusted by connecting ISET to ground through a resistor. When ISET is connected to ground through a resistor the maximum charging current is determined using the following formula:

$$I_{\text{FCHG}} = \frac{3000}{R_{\text{ISET}}}$$

where RISET is a resistor from ISET to ground.

Determine the IFCHG value by considering the characteristics of the battery. It is not necessary to limit charge current based on the capabilities of the expected adapter input, the system load, or thermal limitations of the PCB. The MAX8895\_ automatically adjusts the charging algorithm to accommodate these factors.



Figure 24. Monitoring Charge Current with the ISET Voltage

#### Monitoring Charge Current (ISET)

In addition to setting charge current, ISET can also be used to monitor the actual current charging the battery. The ISET output voltage is:

$$I_{\overline{CHG}} = \left(\frac{V_{ISET}}{R_{ISET}}\right) \times 2000$$

where:

 $\overline{\rm ICHG}$  is the actual battery charge current,  ${\rm R}_{\rm ISET}$  is a resistor from ISET to ground.

A 1.5V output indicates the battery is being charged at the maximum fast-charge current (IFCHG). 0V indicates no charging. The ISET voltage is also used by the charger control circuitry to set and monitor the battery current. Avoid adding more than 10pF of capacitance directly to the ISET pin. If filtering of the charge current monitor is necessary, add a resistor of 100k $\Omega$  or more between ISET and the filter capacitor to preserve charger stability.

If the maximum charge current (IFCHG), is set to the default value, the current monitor function is not available.

#### Charge Termination (IDN)

When the charge current falls to the termination threshold and the charger is in voltage mode, charging is complete. Charging continues for a time period defined by the tCHG\_DONE and then enters the DONE state where charging stops.

The IDN input adjusts the charge current termination threshold. The termination threshold can be fixed by connecting IDN to INT\_3V3 or can be adjusted by connecting IDN to ground through a resistor. When IDN is connected to ground through a resistor, the charge done threshold is determined using the following formula:

$$I_{\text{TERM}} = \frac{2400}{R_{\text{IDN}}}$$

where RIDN is a resistor from IDN to ground.

Note that if charge current falls to ITERM as a result of the input or thermal limiter, the charger does not enter the DONE state. For the charger to enter DONE, charge current must be less than ITERM, the charger must be in voltage mode, and the input or thermal limiter must not be reducing charge current. The charger exits the DONE state and fast-charge resumes if the battery voltage subsequently drops below VBAT\_RECHG or if CEN is cycled. Connecting IDN to INT\_3V3 selects the default termination current threshold.

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

#### Charge Status Outputs Charge Output (CHG) (MAX8895V/MAX8895X/ MAX8895Y Only)

CHG is an active-low, open-drain output that is driven low during charging. CHG is logic-low when the battery charger is in fast-charge and top-off states. When charge current falls to the charge termination threshold and the charger is in voltage mode CHG goes high impedance. CHG holds its current state if the thermistor causes the charger to enter temperature suspend mode. When the MAX8895V/MAX8895X/MAX8895Y are used with a microprocessor, connect a pullup resistor between CHG and the logic I/O voltage to indicate charge status to the microprocessor. Alternatively, CHG can sink up to 20mA for an LED indicator.

#### Prequalification Output (PREQ) (MAX8895V/MAX8895X/MAX8895Y Only)

PREQ is an active-low, open-drain output that is driven low when the charger is in prequalification state. When the MAX8895V/MAX8895X/MAX8895Y are used in conjunction with a microprocessor, connect a pullup resistor between PREQ and the logic I/O voltage to indicate charge status to the microprocessor. Alternatively, PREQ can sink up to 20mA for an LED indicator.

**Fault Output (FLT) and Charge Timer (CT)** FLT is an active-low, open-drain output that is driven low during a battery fault. The fault state occurs when either the prequalification or fast-charge timer expires. The prequalification and fast-charge fault timers are set by CCT:

$$t_{\text{PREQUAL}} = 16 \text{min} \times \frac{C_{\text{CT}}}{0.068 \mu \text{F}}$$
$$t_{\text{FCHG}} = 100 \text{min} \times \frac{C_{\text{CT}}}{0.068 \mu \text{F}}$$

While in fast-charge mode, a large system load or device self-heating may cause the MAX8895\_ to reduce charge current. Under these circumstances, the fast-charge timer adjusts to ensure that adequate charge timer is still allowed. Consequently, the fast-charge timer is slowed by 2x if charge current is reduced below 50% of the programmed fast charge level. If charge current is reduced to below 20% of the programmed level, the fast-charge timer is paused. The fast-charge timer is not adjusted if the charger is in voltage mode where charge current reduces due to current tapering under normal charging.

To exit a fault state, toggle  $\overline{\text{CEN}}$  or remove and reconnect the V<sub>BUS</sub> input source. **Note:** A thermistor out-of-

Maxim Integrated

range or on-chip thermal limit conditions are not considered faults. When the MAX8895V/MAX8895X/MAX8895Y are used in conjunction with a microprocessor, connect a pullup resistor between FLT and the logic I/O voltage to indicate fault status to the microprocessor. Alternatively, FLT can sink up to 20mA for an LED indicator.

#### CHG\_TYPE Output (MAX8895W Only)

The output CHG\_TYPE is used to indicate the type of interface detected. If CHG\_TYPE output is logic level low the input current limit is set to 100mA or less. If CHG\_TYPE output is logic level high the input current limit is set to 500mA or greater.

#### **DET\_DONE** Output (MAX8895W Only)

DET\_DONE is an active low, open-drain output that is driven low once adapter detection is complete. DET\_DONE is high impedance in suspend mode.

#### IBUS\_DEF Output (MAX8895W Only)

The IBUS\_DEF input is only valid when ENU\_EN is set to logic-high activating the adapter type detection. If the adapter type is detected as a USB 2.0 device, the input current limit is set to the programmed value and the MAX8895W does not initiate USB enumeration. If IBUS\_DEF is connected to ground or logic level low, the input current limit is set to 100mA. If IBUS\_DEF is connected to INT\_3V3 or logic level high, the input current limit is set to 500mA.

#### Thermistor Input (THM)

The THM input connects to an external negative temperature coefficient (NTC) thermistor to monitor battery or system temperature. Charging is suspended when the thermistor temperature is out of range. The charge timers are suspended and hold their state, but no fault is indicated. When the thermistor comes back into range, charging resumes and the charge timer continues from where it was at previously. Connecting THM to AGND disables the thermistor monitoring function.

Since the thermistor monitoring circuit employs an external bias resistor from THM to VINT\_3V3 (RTB, Figure 25), the thermistor is not limited only to  $10k\Omega$  (at T<sub>A</sub> = +25°C). Any resistance thermistor can be used as long as the value of RTB is equivalent to the thermistor's T<sub>A</sub> = +25°C resistance. For example, with a  $10k\Omega$  at T<sub>A</sub> = +25°C thermistor, use  $10k\Omega$  at RTB, and with a  $100k\Omega$  at T<sub>A</sub> = +25°C thermistor, use  $10k\Omega$ .

For a typical  $10k\Omega$  at  $T_A = +25^{\circ}C$  thermistor and a  $10k\Omega$ RTB resistor, the charger enters a temperature suspend state when the thermistor resistance falls below  $3.97k\Omega$ (too hot) or rises above  $28.7k\Omega$  (too cold). These limits

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

correspond to a 0°C to +50°C range when using a 10k $\Omega$  NTC thermistor with a beta of 3500. The general relation of thermistor resistance to temperature is defined by the following equation:

$$R_{T} = R_{25} \times e^{\left\{\beta \left(\frac{1}{T+273} - \frac{1}{298}\right)\right\}}$$

 $R_T$  = The resistance ( $\Omega$ ) of the thermistor at temperature T in °C.

 $R_{25}$  = The resistance ( $\Omega$ ) of the thermistor at  $T_A$  = +25°C.

 $\beta$  = The material constant of the thermistor which typically ranges from 3000K to 5000K.

T = The temperature of the thermistor in  $^{\circ}$ C.

Table 4 shows the MAX8895\_ THM temperature limits for different thermistor material constants.

### Table 4. Fault Temperatures for Different Thermistors

THERMISTOR β (K)	3000	3250	3500	3750	4250
$R_{TB}$ (k $\Omega$ ) (Figure 22)	10	10	10	10	10
Resistance at +25°C (k $\Omega$ )	10	10	10	10	10
Resistance at +50°C (k $\Omega$ )	4.59	4.30	4.03	3.78	3316
Resistance at 0°C (k $\Omega$ )	25.14	27.15	29.32	31.66	36.91
Nominal hot trip temperature (°C)	55	53	50	49	46
Nominal cold trip temperature (°C)	-3	-1	0	2	4.5



Figure 25. Thermistor Monitor Circuitry

where:

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

Some designs may require other thermistor temperature limits. The threshold adjustment can be accommodated by changing RTB, connecting a resistor in series and/or in parallel with the thermistor, or using a thermistor with different  $\beta$ . For example, a TA = +45°C hot threshold and TA = 0°C cold threshold can be realized by using a thermistor with a  $\beta$  of 4250 and connecting a 120k $\Omega$  resistor in parallel. Since the thermistor resistance near TA = 0°C is much higher than it is near TA = +50°C, a large parallel resistance lowers the cold threshold, while only slightly lowering the hot threshold. Conversely, a small-series resistance raises the cold threshold, while only slightly raising the hot threshold. Raising RTB lowers both the hot and cold thresholds, while lowering RTB raises both thresholds.

#### **Thermal Shutdown**

Thermal shutdown limits total power dissipation in the MAX8895\_. When the junction temperature exceeds +160°C (typ), the device turns off, allowing the MAX8895\_ to cool. The MAX8895\_ turn on and begin soft-start after the junction temperature cools by 20°C (typ). This results in a pulsed charge current during continuous thermal-overload conditions.

#### External Clock (MAX8895Y)

The MAX8895Y includes full-speed USB 2.0 compatibility. USB 2.0 full speed requires that the system clock of the transceiver is within ±2500ppm, over temperature, aging, etc. Therefore, the MAX8895Y requires an external resonator or clock source to stay within this limit.

The MAX8895Y local oscillator and internal digital clocks are derived from the reference clock at the XIN input.

#### External Crystal/Ceramic Resonator (MAX8895Y)

XIN and XOUT are used to interface to an external 12MHz crystal or ceramic resonator. Connect a 33pF load capacitor from both XIN/XOUT to ground.

Requirements for the external resonator/crystal for MAX8895Y:

Frequency: 12MHz ±0.25%

CLOAD: 33pF ±20%

Drive level: 200µW

Series resonance resistance:  $60\Omega$  (maximum),  $30\Omega$  (typical)

**Note:** Series resonance resistance is the resistance observed when the resonator is in the series resonant condition. This is a parameter often stated by quartz crystal vendors and is called R1. When a resonator is used in the parallel resonant mode with an external load capacitance, as is the case with the MAX8895Y oscillator circuit, the effective resistance is sometimes stated. The effective resistance at the loaded frequency of oscillation is:

$$R_{EFF} = R1 \times \left[ 1 + \left( \frac{C_0}{C_{LOAD}} \right) \right]^2$$

where:

R1 = Series resonance resistance

CO = Crystal capacitor

CLOAD = External load capacitance

For typical C<sub>O</sub> and C<sub>LOAD</sub> values, the effective resistance can be greater than R1 by a factor of 2.

#### External Clock (MAX8895Y)

The MAX8895Y can also be driven from an external clock. The MAX8895Y accepts an external clock input at XIN. The external clock can either be a digital level square wave or sinusoidal and this may be directly coupled to XIN without the need for additional components. If the peaks of the reference clock are above VINT\_3V3 or below ground, the clock signal must be driven through a DC-blocking capacitor (approximately 33pF) connected to XIN.

The external clock source can either be enabled using the  $\overline{\text{UOK}}$  or INT\_3V3 signals depending on if the clock source is active-low or active-high enabled.

If the INT\_3V3 rail is used, ensure that no significant load is taken from this output since this affects the performance of the MAX8895Y.

#### Clock Timing Accuracy (MAX8895Y)

USB 2.0 specification requires the system clock to be within  $\pm 2500$  ppm over temperature, aging, etc. It is recommended to use a clock source with tighter initial accuracy to ensure that over time the accuracy of  $\pm 2500$  ppm is still valid.

#### **ESD** Protection

D+, D-, and VBUS\_ possess extra protection against static electricity to protect the devices up to  $\pm 8$ kV (HBM). The ESD structures withstand high ESD in all operating modes: normal operation, suspend mode, and powered down. VBUS\_ requires 1µF ceramic capacitors connected to ground as close as possible to the pins.

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

#### ESD Test Conditions

ESD performance depends on a variety of conditions. Contact Maxim for a reliability report that documents test setup, test methodology, and test results. Figure 26 shows the Human Body Model, and Figure 27 shows the current waveform generated when discharged into a low impedance. This model consists of a 100pF capacitor charged to the ESD voltage of interest, which then discharges into the test device through a 1.5k $\Omega$  resistor.

### **Applications Information**

#### **Capacitor Selection**

Ceramic X5R or X7R dielectric capacitors are recommended for best operation. When selecting ceramic capacitors in the smallest available case size for a given value, ensure that the capacitance does not degrade significantly with DC bias. Generally, ceramic capacitors with high values and very small case size have poor DC bias characteristics. Evaluate capacitors carefully before using.

#### **Ground Connections**

Minimize trace lengths between the bypass capacitors and ground. Use separate digital/power ground (DGND)

and analog ground (AGND) copper areas, and connect them together at the negative terminal of the battery. The pins and/or external components for KB\_TM, crystal load capacitors, ISET, IDN, CT, thermistor, and INT\_3V3 should connect to a quiet analog ground. All other ground connections should connect to DGND.

#### Recommended PCB Layout and Routing

Place all bypass capacitors for INT\_3V3, V<sub>BUS</sub>, V<sub>BAT</sub>, and V<sub>SYS</sub> as close as possible to the device. Connect the battery to BAT\_A and BAT\_B as close as possible to the device to provide accurate battery voltage sensing. Make all high-current traces short and wide to minimize voltage drops.

When using the MAX8895Y, place the external crystal and load capacitors as close as possible to the MAX8895Y. The crystal and load capacitors should be kept as far away as possible from the D+/D- traces.

Refer to the MAX8895 Evaluation Kit for an example layout. The MAX8895 Evaluation Kit supports the MAX8895V/MAX8895X and MAX8895Y.



Figure 26. Human Body Test Model



Figure 27. Human Body Model Current Waveform

### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **Typical Operating Circuit**



**Chip Information** 

PROCESS: BICMOS

### **Ordering Information**

PART	USB INTERFACE TYPE	PIN-PACKAGE
MAX8895VEWA+T	Low speed	25 WLP
	Low speed	2.36mm x 2.36mm
MAX8895WEWA+T**	Low speed	25 WLP
	Low speed	2.36mm x 2.36mm
MAX8895XEWA+T	Low an and	25 WLP
	Low speed	2.36mm x 2.36mm
MAX8895YEWA+T	Full speed	25 WLP
	rui speed	2.36mm x 2.36mm

**Note:** All devices are specified over the -40°C to +85°C operating temperature range.

+Denotes a lead(Pb)-free/RoHS-compliant package.

T = Tape and reel.

\*\*Contact factory for availability.

# Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **Package Information**

For the latest package outline information and land patterns (footprints), go to <u>www.maximintegrated.com/packages</u>. Note that a "+", "#", or "-" in the package code indicates RoHS status only. Package drawings may show a different suffix character, but the drawing pertains to the package regardless of RoHS status.

PACKAGE TYPE	PACKAGE CODE	OUTLINE NO.	LAND PATTERN NO.
25 WLP	W252D2+1	<u>21-0453</u>	Refer to Applications Note 1891



### Li-Ion Chargers with Smart Power Selector, Adapter Type Detection, and USB Enumeration

### **Revision History**

REVISION NUMBER	REVISION DATE	DESCRIPTION					
0	7/10	Initial release	_				
1	10/10	Added MAX8895W to data sheet	1–38				
2	2/11	Added patent information	1				
3	4/11	Added contact factory note for MAX8895W	1				
4	9/12	Added MAX8895V to data sheet	1–42				



Maxim cannot assume responsibility for use of any circuitry other than circuitry entirely embodied in a Maxim product. No circuit patent licenses are implied. Maxim reserves the right to change the circuitry and specifications without notice at any time. The parametric values (min and max limits) shown in the Electrical Characteristics table are guaranteed. Other parametric values quoted in this data sheet are provided for guidance.

#### Maxim Integrated 160 Rio Robles, San Jose, CA 95134 USA 1-408-601-1000

© 2012 Maxim Integrated

The Maxim logo and Maxim Integrated are trademarks of Maxim Integrated Products, Inc.

45